

Vortex Water Revitalizer Filters Installation

Always install AFTER your existing water treatment system!
Installation can be done one of two ways:

1. Cut the tube that leads out of your existing water treatment system to the spout, and then insert the Vortex Water Revitalizer in between the pieces of tube using the Snap-On Fittings provided.
2. Attach the Vortex Water Revitalizer directly to the spout that delivers your drinking water, also using the Snap-On Fittings provided.



For Any Technical Assistance, Reach Us at
Toll Free 1 (888) 644-7754